



Samsung BD-H5100 Media Controls Replacement

This guide will teach you how to replace the media controls in the Samsung BD-H5100.

Written By: Mira Patel



INTRODUCTION

We will teach the reader how to replace the media controls in the Samsung BD-H5100 in the case the controls don't work anymore when pressed.



TOOLS:

- [Spudger](#) (1)
 - [64 Bit Driver Kit](#) (1)
 - [Phillips #00 Screwdriver](#) (1)
-

Step 1 — Media Controls




- Use the Phillips Head #2 screwdriver to remove the three 10mm screws on the back panel.

Step 2



- Use the plastic spudger to pry open the top panel from the center tab.


 Be careful not to break the ribbon connecting the motherboard on the bottom panel to the top panel.

Step 3



- Pull the ribbon gently from one corner by the blue tab to remove it.

Step 4



- Use a Phillips Head #00 to unscrew the two 7mm screws on the media controls.

Step 5



- Remove the white cover from the media controls.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-19 12:01:28 PM.